

Need a technician? Contact TIMCOD

Scan the QR code or open the contact page. The numbers of our 7 agencies (reception and technical hotline) are on the last page.

<https://www.timcod.fr/contact>



Home › Repair › Barcode scanner troubleshooting › Zebra › MC3300ax

TROUBLESHOOTING GUIDE

Zebra MC3300ax troubleshooting guide: errors, faults and fixes

Updated 21 October 2026 · By TIMCOD maintenance technicians · Source: official Zebra documentation, MC3300ax mobile computer quick start guide (MN-004195-01FR) and MC3300ax data sheet (list at the end of the page)

TIMCOD PRODUCT PAGE (IN FRENCH)

See the Zebra MC33 / MC3300 ax product page →

In brief. The Zebra MC3300ax is the Wi-Fi 6 version of the MC33 Android keypad mobile computer, available in gun-grip (MC3300ax-G) or straight (MC3300ax-S) versions, with an optional BLE beacon battery for finding a mobile computer that is switched off. Zebra reports most faults through the charging/notification light: charging error, battery at end of life, hot swap, incompatible battery. This guide covers charging and compatible batteries, the BLE beacon, Wi-Fi 6, reset, the update to Android 14 and scanning with DataWedge. Click a question to open its troubleshooting entry.

- **The light is flashing or stays red:** find the signal in the [lookup table](#) and open the matching entry.
- **The mobile computer no longer scans, or the barcodes do not arrive:** see [the mobile computer no longer scans](#) and [barcodes do not reach the application](#).

Need a technician? Contact TIMCOD

Scan the QR code or go to www.timcod.fr/contact · numbers of our 7 agencies on the last page



- **Wi-Fi 6, BLE battery or frozen mobile computer:** see [Wi-Fi 6](#), [BLE beacon](#) and [reset](#).
- **The problem keeps coming back:** the [preventive maintenance](#) section explains how it reduces this type of fault.

What do the lights on my Zebra MC3300ax mean? Lookup by signal

The MC3300ax has only one charging/notification light, whose colour and flash rate give information on charging, battery replacement and notifications, plus a scan LED. The table links each signal to its cause and to its troubleshooting entry.

Beep or message	Light (Zebra guide)	Likely cause	Entry
—	○ off	The battery is not charging	The mobile computer does not charge
—	● solid orange	Battery charging (normal)	Charging and lights
—	● solid green	Battery charging complete	Charging and lights
—	● flashing orange	Wireless session active during a battery hot swap	Hot swap

Need a technician? Contact TIMCOD

Scan the QR code or go to www.timcod.fr/contact · numbers of our 7 agencies on the last page



Beep or message	Light (Zebra guide)	Likely cause	Entry
—	● red, flashing rapidly (2 per second)	Charging error: temperature too high or too low, or charging for too long (usually eight hours)	<u>Charging error</u>
—	● solid red	Battery (in the mobile computer or spare) at the end of its useful life	<u>Battery at end of life</u>
—	flashing blue	App notification received (unrelated to charging)	<u>Charging and notification lights</u>
Beep on scanning	● green scan LED	Barcode decoded successfully (default signal)	<u>The mobile computer no longer scans</u>
Battery notification (cannot be disabled)	—	Battery incompatible with the MC3300ax	<u>Battery notification</u>

The light states come from table 3, “Charging/notification LED indicators”, in the French MC3300ax quick start guide (MN-004195-01FR), which also applies to the spare battery. A dash means that the page consulted does not specify the state of the light.

Need a technician? Contact TIMCOD

Scan the QR code or go to www.timcod.fr/contact · numbers of our 7 agencies on the last page



Red light or battery notification on the Zebra MC3300ax: causes and solutions

The fault signals of the charging/notification light and the incompatible battery notification.

Why is the light on my Zebra MC3300ax mobile computer flashing red rapidly?

Light: red, flashing rapidly (2 per second) · Mobile computer or battery charging.

Short answer: The French MC3300ax quick start guide calls this a “charging error”: temperature too high or too low, or charging that has gone on too long without finishing (usually eight hours). Let the mobile computer return to between 0 °C and 40 °C before restarting charging.

LIKELY CAUSE

Table 3 of the quick start guide (“Charging/notification LED indicators”): red flashing rapidly indicates a charging error, caused by the temperature or by charging for too long.

Caution: The MC3300ax quick start guide says to follow the battery safety guidelines in the product reference guide and to charge batteries between 0 °C and 40 °C.

WHAT TO DO

1. Take the mobile computer out of its cradle or unplug the cable, then let it adjust to the temperature.
2. Restart charging in a room between 0 °C and 40 °C, the range specified by Zebra.
3. If a hand strap is fitted, check that it does not obstruct the charging contacts: the guide makes this a condition for correct operation.
4. If the error keeps recurring at a suitable temperature, watch the light after charging: solid red indicates a battery at the end of its life (see [battery at end of life](#)).

Need a technician? Contact TIMCOD

Scan the QR code or go to www.timcod.fr/contact · numbers of our 7 agencies on the last page



Sources: [Charging/notification LED indicators](#) · [Charging the mobile computer](#) – MC3300ax mobile computer quick start guide (MN-004195-01FR Rev. A) (official documentation).

Why does the light on my Zebra MC3300ax mobile computer stay solid red?

Light: solid red · Battery charging or charged.

Short answer: According to Zebra, solid red means that the battery, whether charging or already charged, has reached the end of its useful life. Plan to replace it, for example with the 7,000 mAh PowerPrecision+ battery supplied as standard with the MC3300ax.

LIKELY CAUSE

The MC3300ax quick start guide gives two descriptions for solid red: “The spare battery is charging, but it is at the end of its useful life” and “Battery charging is complete, but the battery is at the end of its useful life”.

Caution: The MC3300ax quick start guide says to follow the battery safety guidelines in the product reference guide and to charge batteries between 0 °C and 40 °C.

WHAT TO DO

1. Identify the battery concerned: the battery in the mobile computer or a spare battery being charged.
2. Set it aside and replace it with a compatible battery: 7,000 mAh PowerPrecision+, the 7,000 mAh BLE beacon version, or the MC3300's 2,740 mAh and 5,200 mAh batteries (see [compatible batteries](#)).
3. After insertion, the light should turn solid orange while charging, then solid green.

Need a technician? Contact TIMCOD

Scan the QR code or go to www.timcod.fr/contact · numbers of our 7 agencies on the last page



Sources: [Charging/notification LED indicators](#) – MC3300ax mobile computer quick start guide (MN-004195-01FR Rev. A) · [Battery](#) – Product Spec Sheet – MC3300ax Mobile Computer (official documentation).

Why does my Zebra MC3300ax mobile computer show a battery notification that cannot be closed?

Message: battery notification every time an unsupported battery is used.

Short answer: According to the quick start guide, a notification appears when an incompatible battery is used, and it can be neither disabled nor removed on the MC3300ax. Install a battery intended for the mobile computer: the 7,000 mAh PowerPrecision+, its BLE beacon version, or the MC3300's 2,740 and 5,200 mAh batteries.

LIKELY CAUSE

The guide states: “the battery notification cannot be disabled or removed”. The data sheet lists the standard 7,000 mAh battery, the optional 7,000 mAh BLE beacon battery and compatibility with the MC3300's 2,740 mAh (1X) and 5,200 mAh (2X) batteries.

Caution: The quick start guide refers to the battery safety guidelines in the MC3300ax product reference guide.

WHAT TO DO

1. Remove the battery (two release buttons) and read its part number.
2. Replace it with one of the batteries Zebra lists for the MC3300ax: 7,000 mAh PowerPrecision+ (supplied), 7,000 mAh with BLE beacon (optional), 5,200 mAh or 2,740 mAh from the MC33 range.
3. Insert it, press firmly and check that both release buttons return to position.

Need a technician? Contact TIMCOD

Scan the QR code or go to www.timcod.fr/contact · numbers of our 7 agencies on the last page



Sources: [Battery notification](#) – MC3300ax mobile computer quick start guide (MN-004195-01FR Rev. A) · [Installing the battery](#) – MC3300ax mobile computer quick start guide (MN-004195-01FR Rev. A) · [Battery](#) – Product Spec Sheet – MC3300ax Mobile Computer (official documentation).

My Zebra MC3300ax no longer scans barcodes: causes and solutions

Scan button, imager range, picklist mode and symbologies.

Why has my Zebra MC3300ax mobile computer stopped scanning barcodes?

Symptoms: no aiming pattern, or an aiming pattern with no green LED and no beep.

Short answer: According to the quick start guide, the scan button and the trigger only start capture if a scanning application is active, with a text field selected. In picklist mode, the mobile computer only decodes once the crosshair of the aiming pattern is placed on the barcode.

LIKELY CAUSE

The quick start guide describes scanning with the internal imager (SE4770 or SE4850-ER) and picklist mode. The DataWedge documentation points out that the symbology must be enabled in the profile's decoders.

WHAT TO DO

1. Open an app and select a text field.
2. Point the scan window at the barcode and press and hold the scan button or the trigger (MC3300ax-G).
3. Place the barcode within the aiming area: a successful decode is indicated by the green scan LED and a beep.

Need a technician? Contact TIMCOD

Scan the QR code or go to www.timcod.fr/contact · numbers of our 7 agencies on the last page



4. Take the distance into account: the data sheet gives up to 60 cm for the standard SE4770 imager and up to 21.4 m for the SE4850 ERI extended-range imager.
5. If only the barcode under the crosshair is read, picklist mode is active: aim precisely, or set **Picklist** to **Disable** in the DataWedge profile.
6. In the DataWedge profile (**Configure scanner settings** > **Decoders**), check that the barcode's symbology is ticked.

The DataWedge documentation advises against the **Auto** illumination mode for continuous scanning sessions in changing lighting.

Sources: [Scanning with the internal imager](#)  – MC3300ax mobile computer quick start guide (MN-004195-01FR Rev. A) · [Data Capture](#)  – Product Spec Sheet – MC3300ax Mobile Computer · [Barcode Input](#)  – Zebra TechDocs – DataWedge (official documentation).

Barcodes scanned by my Zebra MC3300ax do not reach the application: DataWedge

DataWedge profile, prefix, suffix and Enter key.

Why does my Zebra MC3300ax mobile computer not send scanned barcodes to my application?

Symptoms: scanning works in the DataWedge demo app, but not in your software.

Short answer: If scanning works in the DataWedge demo app but not in yours, Zebra explains that a DataWedge profile associated with your application, with a suitable output, is missing. Without this profile, Profile0 applies, without knowing where to send the data.



LIKELY CAUSE

The DataWedge FAQ attributes this symptom to an application without a profile, or to a profile whose input or output is incorrectly configured. Profile0 applies to any application not associated with a profile.

WHAT TO DO

1. In DataWedge, create a profile for your application and associate the application with this profile (an application can only belong to one profile).
2. Configure the Barcode input and an output: Keystroke (keyboard entry) or Intent, depending on your application.
3. Do not disable Profile0 without a dedicated profile: scanning would become impossible in applications that have not been configured.
4. After a restart, wait a few seconds for DataWedge to initialise before scanning.

Sources: [Frequently Asked Questions](#) · [DataWedge Profiles](#) – Zebra TechDocs – DataWedge (official documentation).

How can my Zebra MC3300ax mobile computer add a prefix, a suffix or the Enter key to scanned barcodes?

Short answer: These settings are in the Basic Data Formatting section of the DataWedge profile: “Prefix to data”, “Suffix to data”, “Send TAB key” and “Send ENTER key”. According to Zebra, unticking “Send data” does not prevent the prefix and suffix from being sent.

LIKELY CAUSE

The DataWedge guide describes the basic formatting options; as long as basic formatting is not enabled, the scanned data is sent as is.

Need a technician? Contact TIMCOD

Scan the QR code or go to www.timcod.fr/contact · numbers of our 7 agencies on the last page



WHAT TO DO

1. Open the application's DataWedge profile, then the basic data formatting of the output in use.
2. Fill in **Prefix to data** (characters added at the start) or **Suffix to data** (characters added at the end).
3. Tick **Send ENTER key** to end each scan with Enter, or **Send TAB key** for a tab.
4. Leave **Send data** ticked: if it is unticked, only the prefix and suffix are sent.
5. The **Send as hex** option sends the data in hexadecimal.

Source: [Basic Data Formatting](#) – Zebra TechDocs – DataWedge (official documentation).

Zebra MC3300ax Wi-Fi 6: connection problems

Supported standards and bands, Wi-Fi country and settings enforced by the administrator.

Why won't my Zebra MC3300ax mobile computer connect over Wi-Fi 6?

Symptoms: connection impossible or limited throughput on a Wi-Fi 6 network.

Short answer: According to the Zebra data sheet, the MC3300ax supports Wi-Fi 6 (802.11ax) with 2x2 MU-MIMO on the 2.4 GHz and 5 GHz bands. Check that your access point transmits in 802.11ax on one of these bands and that the mobile computer's Wi-Fi country is correct.

LIKELY CAUSE

The data sheet lists the 802.11a/b/g/n/ac/ax standards and the two bands, 2.4 GHz (up to 286.8 Mbit/s) and 5 GHz (up to 1,201 Mbit/s). Zebra's Wi-Fi Manager documentation explains that the choice of country and permitted bands can be enforced by the administrator.

Need a technician? Contact TIMCOD

Scan the QR code or go to www.timcod.fr/contact · numbers of our 7 agencies on the last page



WHAT TO DO

1. Check that the access point transmits in 802.11ax on 2.4 GHz or 5 GHz: the MC3300ax data sheet does not mention any other band.
2. Country: in “AUTO”, the mobile computer sets itself according to the network's 802.11d beacon. According to Zebra, countries whose infrastructure does not support 802.11d must be selected manually, and not all channels are available in all countries.
3. If your fleet is managed, ask the administrator whether a band selection (for example 2.4 GHz only) or a channel mask has been applied.
4. After a battery replacement, the connection is only maintained for 30 seconds (see [hot swap](#)).

When to call a technician: the connection still fails: according to Zebra, advanced Wi-Fi logging (Fusion, `/fusionlogs` folder) is generally used at the request of Zebra support.

Zebra also lists a power-saving option specific to Wi-Fi 6 (TWT), which requires MX 11.1 or later and Android API 30 or later.

Sources: [WLAN](#) – Product Spec Sheet – MC3300ax Mobile Computer · [Wi-Fi Manager](#) – Zebra TechDocs – MX · [Replacing the battery](#) – MC3300ax mobile computer quick start guide (MN-004195-01FR Rev. A) (official documentation).

My Zebra MC3300ax will not charge: batteries, cradles and BLE beacon

Charging, compatible accessories, hot swap and the BLE beacon battery, according to the quick start guide and the data sheet.

Need a technician? Contact TIMCOD

Scan the QR code or go to www.timcod.fr/contact · numbers of our 7 agencies on the last page



Why won't my Zebra MC3300ax mobile computer charge in its cradle?

Light: off even though the mobile computer is in the cradle or plugged in.

Short answer: When the light stays off, “the battery is not charging”. The MC3300ax guide points out that an incorrectly positioned hand strap can obstruct the charging contacts; also check the accessory used and the temperature (0 °C to 40 °C).

LIKELY CAUSE

Table 3 of the quick start guide: light off = battery not charging. The guide points out that the hand strap, if fitted, must not interfere with the charging contacts.

Caution: The MC3300ax quick start guide says to follow the battery safety guidelines in the product reference guide and to charge batteries between 0 °C and 40 °C.

WHAT TO DO

1. If a hand strap is fitted, move it away from the charging contacts and put the mobile computer back.
2. Use a charging accessory listed by Zebra: single-slot USB charging cradle with spare battery charger (CRD-MC33-2SUCHG-01), 5-slot ShareCradle (with or without Ethernet, with or without a 4-battery charger), USB charging cable (CBL-MC33-USBCHG-01), or single-slot MC32N0 cradle with the MC33XX charge-only adapter.
3. Charge between 0 °C and 40 °C.
4. The light should turn solid orange while charging, then solid green. According to the data sheet, the 7,000 mAh battery fully recharges in less than five hours.
5. A flashing blue light is not related to charging: it indicates that an app notification has been received.

Sources: [Charging/notification LED indicators](#)  – MC3300ax mobile computer quick start guide (MN-004195-01FR Rev. A) · [Charging accessories](#)  – MC3300ax mobile computer quick start guide (MN-004195-01FR Rev. A) · [Battery](#)  – Product Spec Sheet – MC3300ax Mobile Computer (official

Need a technician? Contact TIMCOD

Scan the QR code or go to www.timcod.fr/contact · numbers of our 7 agencies on the last page



documentation).

Why is the light on my Zebra MC3300ax mobile computer flashing orange during a battery change?

Light: flashing orange · Battery being replaced.

Short answer: The MC3300ax is in hot swap mode: the screen goes off, the mobile computer switches to power saving and, according to Zebra, the MC3300ax-G and MC3300ax-S keep their wireless connection for 30 seconds. Put a battery back in within five minutes to retain the RAM contents.

LIKELY CAUSE

The quick start guide associates flashing orange with “an active wireless connectivity session during battery hot swap”. The data sheet refers to temporary persistence of Wi-Fi and Bluetooth sessions.

WHAT TO DO

1. Loosen the hand strap if one is fitted, press the two release buttons and remove the battery.
2. Slide the front of the new battery into the compartment and press firmly until both release buttons return to position.
3. Act within five minutes: this is how long the data in RAM is preserved.
4. The mobile computer reactivates automatically. Press the Power button only if it was switched off or has been without a battery for a long time.

Sources: [Replacing the battery](#)  – MC3300ax mobile computer quick start guide (MN-004195-01FR Rev. A) · [Charging/notification LED indicators](#)  – MC3300ax mobile computer quick start guide (MN-004195-01FR Rev. A) · [Battery](#)  – Product Spec Sheet – MC3300ax Mobile Computer (official documentation).

Need a technician? Contact TIMCOD

Scan the QR code or go to www.timcod.fr/contact · numbers of our 7 agencies on the last page



Why does the BLE battery in my Zebra MC3300ax mobile computer not transmit a beacon once the mobile computer is switched off?

Symptoms: switched-off mobile computer cannot be found with the locating tool, despite the BLE beacon battery.

Short answer: According to Zebra, the secondary BLE beacon only works if the MC33 BLE beacon battery was in the mobile computer before it was powered off, and the mobile computer must be switched on after this battery is inserted. In addition, beacon transmission is disabled by default: it is configured with Beacon Manager.

LIKELY CAUSE

The quick start guide sets two conditions (battery inserted before switching off, mobile computer switched on after insertion). The Beacon Manager documentation states that the settings are only copied to the battery when the mobile computer is switched on, that transmission is disabled by default and that it stops if the battery is removed.

WHAT TO DO

1. Insert the MC33 BLE beacon battery, then switch on the mobile computer so that its settings are copied to the battery.
2. Have the administrator check that transmission (**Beaconing**) is enabled in Beacon Manager: it is disabled by default.
3. If the mobile computer is switched off in Airplane mode, the beacon only transmits if the Airplane mode transmission option is enabled; it is disabled by default.
4. Then switch off the mobile computer without removing the battery: a battery that has been removed stops transmitting. After a configured battery is reinserted, transmission resumes in about 30 seconds.

The data sheet presents this optional 7,000 mAh battery as a solution for locating the mobile computer when it is switched off.

Need a technician? Contact TIMCOD

Scan the QR code or go to www.timcod.fr/contact · numbers of our 7 agencies on the last page



Sources: [MC33 rechargeable Li-Ion battery with BLE beacon](#) – MC3300ax mobile computer quick start guide (MN-004195-01FR Rev. A) · [Beacon Manager](#) – Zebra TechDocs – MX · [Battery](#) – Product Spec Sheet – MC3300ax Mobile Computer (official documentation).

Can my Zebra MC3300ax mobile computer use MC3300x cradles and batteries?

Short answer: Yes: according to the Zebra data sheet, the MC3300ax is backward compatible with existing MC3300x accessories and accepts the MC3300's 2,740 mAh and 5,200 mAh batteries. The quick start guide also lists the single-slot MC32N0 cradle, with the MC33XX charge-only adapter.

LIKELY CAUSE

The data sheet states compatibility with MC3300x accessories and MC3300 batteries; the quick start guide lists the charging accessories for the MC3300ax.

WHAT TO DO

1. Reuse the 5-slot ShareCradles, the single-slot USB cradle and the USB charging cable from the MC33 range.
2. On a single-slot MC32N0 cradle, install the MC33XX charge-only adapter.
3. Check that the hand strap, if fitted, does not interfere with the charging contacts.

Sources: [Battery](#) – Product Spec Sheet – MC3300ax Mobile Computer · [Charging accessories](#) – MC3300ax mobile computer quick start guide (MN-004195-01FR Rev. A) (official documentation).

How do I reset a Zebra MC3300ax and DataWedge?

Restart, Enterprise Reset and Factory Reset, and resetting DataWedge.

Need a technician? Contact TIMCOD

Scan the QR code or go to www.timcod.fr/contact · numbers of our 7 agencies on the last page



How do I reset my Zebra MC3300ax mobile computer?

Short answer: If the software stops responding, press and hold the Power button and choose “Redémarrage” (restart), as the quick start guide describes. The deeper resets, Enterprise Reset and Factory Reset, erase data: keep them for faults that persist.

LIKELY CAUSE

The quick start guide offers “Redémarrage” (restart), which “restarts the mobile computer when the software stops responding”. Zebra's MX documentation defines the resets: a restart keeps settings and apps, Enterprise Reset erases data while preserving the `/enterprise` partition, and Factory Reset erases `/data` , `/cache` and `/enterprise` .

Caution: Enterprise Reset, Factory Reset and Full Device Wipe erase data and apps. Zebra warns that an Enterprise Reset triggered manually without the bypass option may leave the mobile computer in an unexpected state.

WHAT TO DO, FROM THE LIGHTEST TO THE MOST DRASTIC

1. Press and hold the Power button, then tap “Redémarrage” (restart).
2. For a complete shutdown, choose “Mise hors tension” (power off) in the same menu, then switch back on by pressing and holding the Power button until the Zebra splash screen appears.
3. Enterprise Reset: returns to the state defined by the company; according to Zebra, it works like a Factory Reset but keeps the `/enterprise` partition. The mobile computer restarts in Recovery mode.
4. Factory Reset: erases the `/data` , `/cache` and `/enterprise` partitions; removable storage cards are not erased.
5. Full Device Wipe: Factory Reset plus erasure of all storage cards; the mobile computer keeps its Android version.

Need a technician? Contact TIMCOD

Scan the QR code or go to www.timcod.fr/contact · numbers of our 7 agencies on the last page



Sources: [On/Off button](#) ↗ – MC3300ax mobile computer quick start guide (MN-004195-01FR Rev. A) · [Power Manager](#) ↗ – Zebra TechDocs – MX (official documentation).

How do I reset DataWedge on my Zebra MC3300ax mobile computer?

Short answer: In the DataWedge settings, the “Restore defaults” option returns DataWedge to its factory settings. Zebra warns that the operation is irreversible: export the configuration first if you want to keep it.

LIKELY CAUSE

The “DataWedge Settings” page describes restoring the factory settings, and exporting and importing the configuration. It states that a restore deletes the current configuration file.

Caution: Zebra states that the restore cannot be undone (“This action cannot be undone”).

WHAT TO DO

1. Open DataWedge (icon on the home screen or in the app drawer), then the three-dot menu.
2. To back up, use export: the complete configuration is saved to the mobile computer's storage. Do not rename or modify the exported file.
3. Tap **Restore defaults** to return to the factory settings.
4. To reapply a configuration, import the file: the import replaces all the DataWedge settings and profiles on the mobile computer.

Sources: [DataWedge Settings](#) ↗ · [About DataWedge](#) ↗ – Zebra TechDocs – DataWedge (official documentation).

Need a technician? Contact TIMCOD

Scan the QR code or go to www.timcod.fr/contact · numbers of our 7 agencies on the last page



My Zebra MC3300ax will not start or needs to move to Android 14: what should I do?

Powering on and upgrading the Android operating system.

Why won't my Zebra MC3300ax mobile computer switch on?

Symptoms: nothing appears on the screen, even after pressing and holding the Power button.

Short answer: Make sure the battery is properly engaged, with both release buttons back in position, then press and hold the Power button until the Zebra splash screen appears. If the battery is flat, place the mobile computer in its cradle: the light should turn solid orange.

LIKELY CAUSE

The quick start guide describes powering on by pressing and holding the Power button until the Zebra splash screen appears, after a battery installation confirmed by both release buttons returning to position.

WHAT TO DO

1. Loosen the hand strap if necessary, position the battery, slide its front into the compartment and press firmly.
2. Check that both release buttons have returned to position, then retighten the hand strap.
3. Press and hold the Power button until the Zebra splash screen appears.
4. With the BLE beacon battery, Zebra says to power on the mobile computer after inserting the battery.
5. If the mobile computer starts but stops responding, see [reset the MC3300ax](#).

Sources: [Installing the battery](#) · [Powering on](#) · [Charging/notification LED indicators](#) – MC3300ax mobile computer quick start guide (MN-004195-01FR Rev. A) (official documentation).

Need a technician? Contact TIMCOD

Scan the QR code or go to www.timcod.fr/contact · numbers of our 7 agencies on the last page



Can my Zebra MC3300ax mobile computer be upgraded to Android 14?

Short answer: Yes: the Zebra data sheet states that the MC3300ax can be upgraded to Android 14 and is covered by LifeGuard, Zebra's Android security update programme. The update restarts the mobile computer in Recovery mode.

LIKELY CAUSE

MC3300ax data sheet: "Upgradeable to Android 14", with LifeGuard. The MX documentation (Power Manager) describes updating the operating system from a Zip file or an update list, with a restart in Recovery mode.

WHAT TO DO

1. The operating system update is applied from a Zip file or an update list, according to Zebra's MX documentation.
2. Apply it: the mobile computer restarts in Recovery mode during installation.
3. According to Zebra, since Android 8, the operating system update action can only be used to upgrade: it cannot be used to go back to an earlier version.

The data sheet also mentions Enterprise Browser, supplied free of charge with the MC3300ax.

Sources: [Operating System](#)  – Product Spec Sheet – MC3300ax Mobile Computer · [Power Manager](#)  – Zebra TechDocs – MX (official documentation).

Other questions about the Zebra MC3300ax: microSD card

Installing the microSD card without risk of electrostatic discharge.

Need a technician? Contact TIMCOD

Scan the QR code or go to www.timcod.fr/contact · numbers of our 7 agencies on the last page



How do I install a microSD card in my Zebra MC3300ax mobile computer without damaging it?

Short answer: The Zebra guide says to observe precautions against electrostatic discharge: anti-static mat and earthed operator. Remove the cover, open the holder, insert the card with the contacts facing down, then close the holder and refit the cover.

LIKELY CAUSE

microSD card installation section of the quick start guide, with an ESD warning.

Caution: “Observe electrostatic discharge (ESD) precautions” to avoid damaging the microSD card (Zebra quick start guide).

WHAT TO DO

1. Work on an anti-static mat, with the operator earthed.
2. Remove the access cover and open the card holder.
3. Insert the microSD card, contacts facing down.
4. Close the holder, then refit the cover.

Source: [Installing the microSD card](#)  – MC3300ax mobile computer quick start guide (MN-004195-01FR Rev. A) (official documentation).

When should you call a technician for a Zebra MC3300ax mobile computer?

The troubleshooting entries above first suggest a setting, recharging or a reset. In the following case, the documentation refers you to support:

Need a technician? Contact TIMCOD

Scan the QR code or go to www.timcod.fr/contact · numbers of our 7 agencies on the last page



- **Wi-Fi 6 still failing:** The connection still fails: according to Zebra, advanced Wi-Fi logging (Fusion, /fusionlogs folder) is generally used at the request of Zebra support.

Avoiding recurring faults on the Zebra MC3300ax mobile computer: preventive maintenance

Worn battery, unstable Wi-Fi, system not up to date: several entries in this guide cover points that a preventive maintenance visit checks before they cause a breakdown.

TIMCOD preventive maintenance is part of the through-life maintenance (MCO). TIMCOD provides for your fleet (page in French). In particular, it includes:

Preventive battery replacement

Recommended every 18 to 24 months, for removable batteries.

Wi-Fi coverage audit

Installation, coverage survey (site survey) and improvement.

General check of the devices

Each device checked and cleaned, minor faults fixed and a report provided.

Security patch updates

Installation of Android updates, where feasible.

Inventory of the fleet under contract

Type, configuration and IP address of each device.

Training and skills transfer

Transfer of technical skills on using the equipment.

Detailed report

Inventory, condition of the fleet and optimisation advice.

Need a technician? Contact TIMCOD

Scan the QR code or go to www.timcod.fr/contact · numbers of our 7 agencies on the last page



In addition, TIMCOD corrective maintenance includes phone support (hotline), repair to working order, express exchange with a replacement device and, as an option, SWAP. Maintenance contracts come in three levels (Essentiel, Confort, Premium).

Zebra MC3300ax mobile computer troubleshooting: frequently asked questions

How do I reset a Zebra MC3300ax?

Press and hold the Power button and choose Redémarrage (restart) when the software stops responding. If the fault persists, Enterprise Reset erases the data while keeping the /enterprise partition, and Factory Reset also erases that partition. Both of these resets restart the mobile computer in Recovery mode. [See the detailed entry.](#)

Is the Zebra MC3300ax Wi-Fi 6 compatible?

Yes. According to the Zebra data sheet, the MC3300ax supports Wi-Fi 6 (802.11ax) with 2x2 MU-MIMO, on the 2.4 GHz and 5 GHz bands. Check that the access point transmits in 802.11ax on one of these bands and that the Wi-Fi country is correct. [See the detailed entry.](#)

What does a flashing red light on a Zebra MC3300ax mean?

Red flashing rapidly indicates a charging error: temperature too high or too low, or charging that goes on too long without finishing, usually eight hours. Recharge between 0 and 40 degrees. Solid red indicates a battery at the end of its life. [See the detailed entry.](#)

Need a technician? Contact TIMCOD

Scan the QR code or go to www.timcod.fr/contact · numbers of our 7 agencies on the last page



How does the BLE battery in the Zebra MC3300ax work?

The MC33 BLE beacon battery transmits a locating signal when the mobile computer is switched off. It must be in the mobile computer before it is powered off, and the mobile computer must be switched on after the battery is inserted. Transmission is disabled by default and is configured with Beacon Manager. [See the detailed entry.](#)

Which battery should I use in a Zebra MC3300ax?

The standard battery is the 7,000 mAh PowerPrecision+; a 7,000 mAh version with a BLE beacon is available as an option. According to the data sheet, the MC3300ax also accepts the MC3300's 2,740 and 5,200 mAh batteries. An incompatible battery triggers a notification that cannot be disabled. [See the detailed entry.](#)

Can the Zebra MC3300ax be upgraded to Android 14?

Yes, the Zebra data sheet states that the MC3300ax can be upgraded to Android 14 and is covered by the LifeGuard security update programme. The update restarts the mobile computer in Recovery mode. [See the detailed entry.](#)

Do MC3300x cradles work with the MC3300ax?

Yes, according to the Zebra data sheet, the MC3300ax is backward compatible with existing MC3300x accessories. The quick start guide also lists the single-slot MC32N0 cradle, provided that the MC33XX charge-only adapter is used. [See the detailed entry.](#)

Need a technician? Contact TIMCOD

Scan the QR code or go to www.timcod.fr/contact · numbers of our 7 agencies on the last page



Sources consulted

All the causes, procedures and signals in this guide come from the pages of the official Zebra documentation listed below, consulted on 20 October 2026.

- [MC3300ax mobile computer quick start guide](#)  – MC3300ax mobile computer quick start guide (MN-004195-01FR Rev. A) **official**
- [MC3300ax Mobile Computer](#)  – Product Spec Sheet – MC3300ax Mobile Computer **official**
- [Barcode Input](#)  – Zebra TechDocs – DataWedge **official**
- [DataWedge Profiles](#)  – Zebra TechDocs – DataWedge **official**
- [Frequently Asked Questions](#)  – Zebra TechDocs – DataWedge **official**
- [Basic Data Formatting](#)  – Zebra TechDocs – DataWedge **official**
- [DataWedge Settings](#)  – Zebra TechDocs – DataWedge **official**
- [About DataWedge](#)  – Zebra TechDocs – DataWedge **official**
- [Power Manager](#)  – Zebra TechDocs – MX **official**
- [Wi-Fi Manager](#)  – Zebra TechDocs – MX **official**
- [Beacon Manager](#)  – Zebra TechDocs – MX **official**

The MC3300ax product reference guide for Android 11 (mc3300ax-a11-prg-en.pdf, MN-004130-02EN), the English version of the quick start guide (mc3300ax-qsg-en.pdf), the HTML page of the data sheet and the MC3300ax support page were not consulted for this guide and are not cited. If the fault falls under these documents, refer to the manufacturer's documentation or ask the TIMCOD technicians.

See also

- Product page on timcod.fr (in French): [Zebra MC33 / MC3300 ax](#)
- All troubleshooting guides for Zebra scanners and mobile computers ([DS3600](#), [FS10](#), [FS20](#), [FS40 / FS70](#), [MC3200](#), [MC3300](#), [MC3300x](#), [MC3400](#), [MC9190-G](#), [MC9200](#), [MC9300](#), [MC9400](#), [TC22R](#), [TC8000](#), [TC8300](#))
- [Maintenance and repair of Zebra mobile computers](#)
- [All barcode scanner and mobile computer troubleshooting guides, all brands](#)
- [TIMCOD repair and maintenance](#)

Need a technician? Contact TIMCOD

Scan the QR code or go to www.timcod.fr/contact · numbers of our 7 agencies on the last page



- [Through-life maintenance \(MCO\): preventive and corrective maintenance](#) (in French)
- [TIMCOD, Zebra reseller](#) (in French)
- [Industrial scanners and mobile computers](#) (in French)

Need a technician? Contact TIMCOD

Scan the QR code or go to www.timcod.fr/contact · numbers of our 7 agencies on the last page



OUR AGENCIES IN FRANCE

7 TIMCOD agencies covering all of France

125 experts across 7 agencies, from Lille to Aix-en-Provence. Call the reception desk or the technical hotline of the agency nearest to your sites.

Contact TIMCOD

A question, a persistent fault, a repair request? Write to us from the contact page on [timcod.fr](https://www.timcod.fr), or call one of our 7 agencies below.

<https://www.timcod.fr/contact>

TIMCOD Nord

495 rue Lavoisier
59112 Annoeullin

📞 RECEPTION	+33 3 74 45 45 35
🔧 TECHNICAL HOTLINE	+33 3 74 45 45 37

TIMCOD Île-de-France

10 A rue Blaise Pascal, Bâtiment C
78990 Élancourt

📞 RECEPTION	+33 1 77 04 86 26
🔧 TECHNICAL HOTLINE	+33 1 77 04 86 30

TIMCOD Est

7 rue Icare
67960 Entzheim

📞 RECEPTION	+33 3 68 33 29 10
🔧 TECHNICAL HOTLINE	+33 3 68 41 90 80

TIMCOD Ouest

7 bis rue Augustin Fresnel
44470 Carquefou

📞 RECEPTION	+33 2 28 00 99 99
🔧 TECHNICAL HOTLINE	+33 2 28 00 99 84

TIMCOD Rhône-Alpes

40 route de Lyon, PA de Chambetière
69960 Corbas

📞 RECEPTION	+33 4 26 22 15 20
🔧 TECHNICAL HOTLINE	+33 4 26 22 15 15

TIMCOD Sud-Ouest

3 impasse de los Appares
31790 Saint-Jory

📞 RECEPTION	+33 5 34 66 61 46
🔧 TECHNICAL HOTLINE	+33 5 34 66 76 88

TIMCOD Sud-Est

545 rue François Hennebique, ZI Milles
13290 Aix-en-Provence

📞 RECEPTION	+33 4 42 60 78 78
🔧 TECHNICAL HOTLINE	+33 4 42 60 78 76

PDF version of the page <https://www.timcod.fr/reparation/en/barcode-scanner-troubleshooting/zebra/mc3300ax>, updated on 21 October 2026.

Need a technician? Contact TIMCOD

Scan the QR code or go to www.timcod.fr/contact · numbers of our 7 agencies on the last page

